

J-BAR INSTALLATION INSTRUCTIONS

RECOMMENDED TOOLS: Screw Driver or Drill

IF ONLY INSTALLING LOWER J-BAR:


(If installing upper and lower J-Bar go to next page for directions)



Mount the J-Bar to the wall in desired position.

If using punched and slotted J-Bar, screws can be placed through pre-drilled holes.

If using standard J-Bar, screws must be drilled through the back of the J-Bar.




Apply adhesive if necessary to the back of infill.

Slide infill into place inside the J-Bar



Ensure that the infill is flush against the back surface. Attach clips to sides and top if required.



Contact Our Team Of Experts If You Have Any Questions Or Need Additional Assistance At 800.325.7513

www.morseindustries.com WHOLESALE ONLY: 800.325.7513



IF INSTALLING UPPER AND LOWER J-BAR:



Mount the bottom J-Bar to the wall in desired position.

If using punched and slotted J-Bar, screws can be placed through pre-drilled holes.

If using standard J-Bar, screws must be drilled through the back of the J-Bar.

2

Mount the upper J-Bar to the wall in desired position.

If using punched and slotted J-Bar, screws can be placed through pre-drilled holes.

If using standard J-Bar, screws must be drilled through the back of the J-Bar.

IMPORTANT: Upper J-Bar should be located at a height that will allow for the infill to be slid into place, while still ensuring that the upper edge of the infill is captured by the upper J-Bar channel. At a minimum, this distance will be the height of the lower J-Bar front, plus the height of the infill.

3

To mount the infill in the J-Bars:

- 1. Add adhesive to back of infill if necessary.
- 2. Slide the top of the infill into the upper J-Bar
- 3. Place the infill flush with the wall behind.
- 4. Drop infill into the channel of the bottom J-Bar.

